



Custom Shower Base

Installation Guide:

- Proper Installation Requires a level subfloor
- Shower base is installed on top of levelling mortar with water dam tight to the stud
- Moisture resistant drywall or waterproof tile backer sits directly on top of water dam
- Solid panel or tile sits directly on shower base

